



## Shanghai Gibo Star International Trade Co., Ltd

Add: 13/F, Ji Mo Road, Pu Dong New Area, Shanghai, PR. China, 200120  
Tel: 86 21 5882 9477 Fax: 86 21 5887 5235 [www.heatsupport.com](http://www.heatsupport.com)

---

### Battery Unit Usage Instruction

#### A. Li-polymer battery-7.4V 4400mAh Digi-display/5-rated

1. Press ON/SETUP button for two seconds until the screen appears "5", and in about 3 seconds, it will switch to its left-volume percentage, namely, a figure with a point. For this rate, the output power is 100% and the temperature reaches to 52°C-55°C.



2. Press ON/SETUP button again, the screen shows "4", and in about 3 seconds, it will switch to its left-volume percentage, namely, a figure with a point. For this rate, the output power is around 80% and the temperature reaches 48°C-51°C.



3. Press ON/SETUP button for the third time, the screen appears "3", and in about 3 seconds, it will switch to its left-volume percentage, namely, a figure with a point. For this rate, the output power is around 60% and the temperature reaches 44°C-47°C.



4. Press ON/SETUP button for the fourth time, the screen shows "2", and in about 3 seconds, it will switch to its left-volume percentage, namely, a figure with a point. For this rate, the output power is around 40% and the temperature reaches 40°C-43°C.



5. Press ON/SETUP button for the fifth time, the screen shows "1", and in about 3 seconds, it will switch to its left-volume percentage, namely, a figure with a point. For this rate, the output power is around 25% and the temperature reaches 37°C-39°C.



## Shanghai Gibo Star International Trade Co., Ltd

Add: 13/F, Ji Mo Road, Pu Dong New Area, Shanghai, PR. China, 200120

Tel: 86 21 5882 9477

Fax: 86 21 5887 5235

[www.heatsupport.com](http://www.heatsupport.com)



6. Press ON/SETUP for the sixth time, the screen turns off, the system will be power off automatically.

### B. Charge instruction:

When the battery is charging, the flashing point on the screen indicates the battery is under charging. The figure refers to the current charging volume. When the figure increases to "9", it means the battery is full and the point becomes stationary. Meanwhile, the LED on charger turns on green.

#### *Important Notice:*

1. Not allow to put the Li-polymer battery into water, fire or in a high-temperature environment. Not allow to punch or scratch lithium-ion battery. Not allow to connect the two ends of the battery to cause a short circuit. Don't take apart, re-assemble, repair battery, heater and charger to avoid breaking of the components.
2. Don't leave it on high temperature for long time to avoid low-temperature skin burning.
3. No permitted to use by the pregnant, baby and the non-vocal disabled. Not permitted to use by serious heart disease patient and carriers of artificial heart pacemaker. Not permitted to use by the blood-bleeding person or the person of bleed symptoms.
4. Don't pierce heater with sharp object.

#### *Production maintenance & storage:*

1. For the first use, please charge the battery to full level. After the LED light turns on green, don't charge for long time any more.
2. The battery will be run out if not using. **Special suggestion:** please charge the battery every 3-5 months and place in cool environment.
3. Battery set; heater and charger should be place away from water. Please take off battery, heater before washing the product and make sure to connect the power to the product until it is dry.
4. When pull the connector out of socket, please hold the connector tightly. Don't stretch the



## Shanghai Gibo Star International Trade Co., Ltd

Add: 13/F, Ji Mo Road, Pu Dong New Area, Shanghai, PR. China, 200120

Tel: 86 21 5882 9477

Fax: 86 21 5887 5235

[www.heatsupport.com](http://www.heatsupport.com)

---

wire to break or destroy the plug.

5. Please place the product in a drafty and dry environment. The relative humidity is less than 80%, no corrosive gas.